


OPERATING INSTRUCTIONS

1. Replace purge vial with labeled sample vial.
2. Turn Valve 1 to SPL LOAD position for at least 30 sec.
3. Turn VALVE 1 back to SPL INJECT position. Allow to purge vial for at least 30 sec.
4. Turn VALVE 2 to OFF position.
5. Remove sample vial and replace with purge vial.
6. Turn VALVE 2 back to ON position.



Drawing # 100096	Scale 45%	Date 09/05/95
Revision # R0		Date
TITLE: Fixed Volume, 50 cc Sample, 2oz Bottle, CF		 a division of PMMI, INC. Old Ocean, Texas 77463 Ph (409)647-4421 Fax (409)647-5041