


Notes:

- A. Relief pressure to be set at 500 PSIG
- C. Use paste teflon sealant over teflon tape on all screwed connections

Drawing # 100023	Scale 45%	Date 01/13/94
Revision # R2		Date 06/15/98
TITLE: Sample Cylinder W/Relief without Outage Tube		 a division of PMMI, INC. Old Ocean, Texas 77463 Ph (409)647-4421 Fax (409)647-5041