


OPERATING INSTRUCTIONS

1. Set Sample Valve to SAFE.
2. Remove Flex Line from fixed quick connect.
3. Connect Sample Cylinder to Gas Sampler.
4. Open Valves on Sample Cylinder.
5. Turn Gas Sampler Valve to SAMPLE.
6. Purge for 10 sec.
7. Close top Sample Cylinder valve first, wait 10 sec. & close bottom Sample Cylinder valve.
8. Set Sample Valve to SAFE.
9. Remove Sample Cylinder.
10. Replace Flex Line in fixed quick connect.

LP-33
S-2004
C3 / C4 PRODUCT
DEBUTANIZER

Drawing # 100136	Scale 25%	Date 10/10/97
Revision # R0		Date
TITLE: Gas Sampler, Single Valve, Hoke Cyl, w/Gauge		 a division of PMMI, INC. Old Ocean, Texas 77463 Ph (409)647-4421 Fax (409)647-5041